



[Introduction](#)

[Prerequisites](#)

[Hardware requisites](#)

[Software requisites](#)

[Intrinsic calibration](#)

[Check the calibration status](#)

[Eye Hand Calibration](#)

[Mounting the chessboard](#)

[Calibration recorder](#)

[Launching calibration estimator](#)

[Verifying the calibration](#)



## Introduction

This is a user guide to perform the calibration of the robot. It consists of two steps that have to be performed in the provided order:

1. Intrinsic camera calibration
2. Check the initial calibration status
3. Eye-hand calibration procedure


## Prerequisites

Here the hardware and software need to successfully perform the outlined procedure as described.

## Hardware requisites

The following components are required in order to do the eye-hand calibration. You should have received a kit with three items:

1. A calibration chessboard
2. Locking 3D printed part for the PAL Gripper
3. Fasteners for the previous.





## Software requisites

Here one has to check whether all required packages are installed in the robot.

### For TIAGo

1. tiago\_description\_calibration
2. pal\_eye\_hand\_calibration\_tiago

### For TIAGo++

1. tiago\_dual\_description\_calibration
2. pal\_eye\_hand\_calibration\_tiago\_dual

To do so first connect to the robot via ssh:

```
ssh pal@tiago-Xc
```

Recall that here X stands for the serial number of your TIAGo robot, without leading 0s.

Once in the robot, you can check whether these packages are installed by doing:

```
dpkg -l | grep calibration
```

You should see, listed:

### For TIAGo

```
pal-<distro>-tiago-description-calibration  
pal-<distro>-pal-eye-hand-calibration-tiago
```


### For TIAGo++

```
pal-<distro>-tiago-dual-description-calibration  
pal-<distro>-pal-eye-hand-calibration-tiago-dual
```



## Intrinsic calibration

First of all, it is necessary to calibrate the intrinsic parameters of the camera. For this purpose it is recommended to have a big chessboard like the one shown below:



In the above example, the size of the chessboard cells is 10.8 cm and there are 8x6 intersections.

In order to calibrate the intrinsics, connect to the robot with X server support, and run the following commands:

```
ssh -X pal@tiago-Xc
pal-stop head_manager
roslaunch camera_calibration cameracalibrator.py --size 8x6 --square 0.108
image:=/xtion/rgb/image_raw camera:=/xtion/rgb --approximate=0.1
_image_transport:=compressed
```

**WARNING:** make sure to adapt the last command to account for the right dimensions of your chessboard.

Follow the instructions in the link:

[http://wiki.ros.org/camera\\_calibration/Tutorials/MonocularCalibration](http://wiki.ros.org/camera_calibration/Tutorials/MonocularCalibration)

**WARNING:** Remember to push the button **Calibrate** and when the calibration is computed (it will takes few minutes) push **Commit** to save the calibration data in the default ros directory and file, i.e. `/home/pal/.ros/camera_info/rgb_xtion.yaml`, before closing the node.



## Check the calibration status

Unfold the arm of the robot by running first the [offer](#) motion. You can either do it via Web Commander in the Movements Tab, or by connecting to the robot and running the corresponding motion:

```
ssh pal@tiago-Xc
```

```
roslaunch play_motion run_motion offer (TIAGo)
```

```
roslaunch play_motion run_motion offer_both (TIAGo++)
```

Wait until the execution is finished and then stop the head\_manager. Do it from the Web Commander in the Startup tab or by running the following command in the robot:

```
pal-stop head_manager
```

Use the following calibration motion to put the robot arm(s) in the so-called *check\_calibration* position from inside the robot:

### For TIAGo

```
roslaunch load `rospack find
```

```
pal_eye_hand_calibration_tiago`/config/tiago_calibration_motions.yaml
```

```
roslaunch play_motion run_motion check_calibration
```

### For TIAGo++

```
roslaunch load `rospack find
```

```
pal_eye_hand_calibration_tiago_dual`/config/tiago_dual_calibration_motions.yaml
```

```
roslaunch play_motion run_motion check_left_calibration
```

```
roslaunch play_motion run_motion check_right_calibration
```

Then from your development computer use RViZ to verify the calibration:

```
export ROS_MASTER_URI=http://tiago-Xc:11311
```

```
roslaunch rviz rviz -d `rospack find tiago_bringup`/config/tiago.rviz
```



Take a snapshot of the “RGB-D camera” viewer where the model of the end-effector will appear overlaid on the actual end-effector. You may disable the “Point cloud” viewer to better see the match between the real end-effector and the overlaid one.

Move the end-effector slightly to have another point of view. You can do it connected to the robot via ssh:

## For TIAGo

```
rosrun play_motion move_joint arm_7_joint 0.02 0.5
```

## For TIAGo++

```
rosrun play_motion move_joint arm_left_7_joint 0.02 0.5
rosrun play_motion move_joint arm_right_7_joint 0.02 0.5
```

Take another snapshot with this configuration. The snapshots should look like as below:



A misalignment of the end-effector between the model and the actual one is clear in the figure above.



## Eye Hand Calibration

### Mounting the chessboard

The Eye-hand calibration procedure should be done with the PAL Gripper. Please change the end-effector to the PAL Gripper following the instructions of the user manual.

First move the robot to a suitable pose to mount the chessboard. Put the robot in *offer* position as done above for the calibration check: either from the Web Commander or by connecting first to the robot and running the offer motion:

```
ssh pal@tiago-Xc
```

```
roslaunch play_motion run_motion offer (TIAGo)
```

```
roslaunch play_motion run_motion offer_both (TIAGo++)
```

After this, close the gripper with the following motion:

#### For TIAGo

```
roslaunch play_motion run_motion close_gripper
```

#### For TIAGo++

```
roslaunch play_motion run_motion close_left
```

```
roslaunch play_motion run_motion close_right
```

Or via the corresponding button in the Web commander. Feel free to move the 7th joint of the arm to put it in a position that eases the mounting of the rest of the parts.


Then mount the chessboard as described below.

1. For the gripper of interest, reduce the current from a development PC:

```
export ROS_MASTER_URI=http://tiago-Xc:11311
```

```
roslaunch rqt_current_limit_controller rqt_current_limit_controller
```

And set the limit current of the corresponding controller to its minimum value, as shown below



*Note that for a single armed TIAGo, only a single slider will appear.*

2. This will allow you to open the gripper freely.  
Attach the printed part in between the gripper fingers:



3. After this is done, close the gripper manually and set back the current limit to its maximum value in `rqt_current_limit_controller`





#### 4. Attach the chessboard using a wrench and an allen key





### For TIAGo

The chessboard should face the left hand side of the robot



### For TIAGo++

The chessboard should be aimed as shown in the two pictures below




**WARNING:** The chessboard should not move from inside of the gripper, otherwise the calibration will have no sense. Make sure that the fasteners are tightly fixed.

**WARNING:** For TIAGo++, with the WebCommander move the arm\_1 joint of the arm you are not calibrating in a way that it cannot collide with the other arm. Do as shown in the picture above.



## Calibration recorder

To record the calibration data make sure to move the robot to a place with a large empty area around to prevent collisions. Use the following sketch as a guide:



First of all, disable the **head\_manager** node, which commands the robot's head, as follows:

```
ssh pal@tiago-Xc
```

```
pal-stop head_manager
```

Then run the calibration recorder as follows. Remember to specify the name of the recorded data and the correct end effector, which in this case is always *gripper*.

### For TIAGo

```
roslaunch pal_eye_hand_calibration_tiago tiago_calibration_recorder.launch  
recorder_name:=test end_effector:=gripper
```

### For TIAGo++

For the left arm:



### For TIAGo

```
roslaunch pal_eye_hand_calibration_tiago_dual tiago_dual_calibration_recorder.launch  
side:=left end_effector:=gripper recorder_name:=test_left_1
```

For the right arm:

Wait until the procedure has finished for the left arm and then mount the chessboard in the end and then follow again the steps outlined above. After this, run:

```
roslaunch pal_eye_hand_calibration_tiago_dual tiago_dual_calibration_recorder.launch  
side:=right end_effector:=gripper recorder_name:=test_right_1
```

**WARNING:** The default ros folder is `~/ros` . The `recorder_name` will be saved in this folder.

The calibration recorder will move the robot to 500 different poses. This process takes about 1h.

When the recording is completed the following messages will appear in the console:

```
[ INFO] [1510220122.672553836]: Finished recording calibration data  
[pal_robot_calibration_recorder-2] process has finished cleanly  
log file:  
/tmp/ros_logs/341b9aa6-c520-11e7-b275-80193476cfcd/pal_robot_calibration_recorder  
-2*.log
```

Press CTRL+C in order to terminate the node.



## Launching calibration estimator

Once the iterations have finished, you must launch the calibration estimator to keep the values recorded:

### For TIAGo

```
roslaunch pal_eye_hand_calibration_core calibration_estimator.launch recorder_name:=test  
robot:=tiago
```

### For TIAGo++

```
roslaunch pal_eye_hand_calibration_core calibration_estimator.launch  
recorder_name:=test_left_1 recorder_name_2:=test_right_1 robot:=tiago_dual
```

Example output:

```
Estimated camera position: 0.0469328 0.0681747 0.0148909  
Original camera position: 0.0908 0.08 0  
Estimated camera orientation RPY: -1.5578 0.00626016 0.0182208  
Original camera orientation: -1.57 0 0  
*****  
Estimated tip Position: 2.49622e-05 0.0167143 0.185674  
Original tip position: 0 -0 0.19  
Estimated tip orientation RPY: 1.54626 0.025915 -0.00531544  
Original tip orientation: 1.57 0 0  
joint offsets:  
arm_1_joint: -0.0350499  
arm_2_joint: 0.0260576  
arm_3_joint: 0.00495167  
arm_4_joint: 0.0442725  
arm_5_joint: -0.0418086  
arm_6_joint: 0.0366973  
arm_7_joint: 0.00238509
```



```
head_1_joint: 0  
head_2_joint: 0.0121784
```

After the results appear, the following message will keep being printed:

```
[INFO] [1510660349.464763243]: Waiting for subscriber
```

Press CTRL+C to terminate the calibration estimation node in the robot. The node will generate also the file with the calibration parameters in:

[~/ros/\[name of the recorder\]/calibration\\_constants.urdf.xacro](#)

**IMPORTANT:** [Unmount the calibration chessboard](#) before proceeding with the following steps.

For the changes to have an effect, you must do the following command:

[pal\\_restart\\_deployer](#)

And after that, reboot the robot. Then, put the robot back in home position and proceed to check the calibration results.

## Verifying the calibration

Proceed as in the Check the calibration status section.